

**MAIN MENU**

<b>SETUP MODE</b>	<b>UTILITY FUNC.</b>	<b>GUIDED TOUR</b>	<b>OBJECT CATALOG</b>	<b>IDENTIFY</b>
<ul style="list-style-type: none"> <li>— <b>Date</b></li> <li>— <b>Time</b></li> <li>— <b>Observ. Site</b> <ul style="list-style-type: none"> <li>- Enter location</li> <li>- Set Time Zone</li> </ul> </li> <li>— <b>Daylight Saving</b> <ul style="list-style-type: none"> <li>- NO</li> <li>- YES</li> </ul> </li> <li>— <b>Alignment</b> <ul style="list-style-type: none"> <li>- 1-Star Align.</li> <li>- 2-Star Align.</li> <li>- 3-Star Align.</li> </ul> </li> <li>— <b>Alignment Stars</b> <ul style="list-style-type: none"> <li>- Auto Select</li> <li>-- ON/OFF</li> <li>- Sort by</li> <li>-- Magnitude</li> <li>-- Alphabet</li> </ul> </li> <li>— <b>Backlash</b> <ul style="list-style-type: none"> <li>- Set Backlash</li> <li>-- RA .....</li> <li>-- DEC ...</li> </ul> </li> <li>— <b>Tracking</b> <ul style="list-style-type: none"> <li>- Sidereal Rate</li> <li>- Lunar Rate</li> <li>- Solar Rate</li> <li>- PEC + Sidereal</li> <li>- Stop Tracking</li> </ul> </li> <li>— <b>Auto Guide Speed</b> <ul style="list-style-type: none"> <li>- 0.125x</li> <li>- 0.25x</li> <li>- 0.5x</li> <li>- 0.75x</li> <li>- 1.0x</li> </ul> </li> <li>— <b>Handset Setting</b> <ul style="list-style-type: none"> <li>- LCD Contrast</li> <li>- Beep Volume</li> <li>- LED Backlight</li> <li>- LCD Backlight</li> </ul> </li> <li>— <b>Factory Setting</b> <ul style="list-style-type: none"> <li>- 1) Yes</li> <li>- 2) Yes</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>— <b>Show Position</b></li> <li>— <b>Show Information</b> <ul style="list-style-type: none"> <li>- Time</li> <li>- Version</li> <li>- Temperature</li> <li>- Power Voltage</li> <li>- Polaris Pos.</li> </ul> </li> <li>— <b>Park Scope</b> <ul style="list-style-type: none"> <li>- HOME position</li> <li>- Current pos.</li> <li>- Custom pos.</li> </ul> </li> <li>— <b>PAE</b> <ul style="list-style-type: none"> <li>- Re-centering obj</li> </ul> </li> <li>— <b>Clear PAE data</b> <ul style="list-style-type: none"> <li>- 1) YES</li> <li>- 2) NO</li> </ul> </li> <li>— <b>PEC Training</b> <ul style="list-style-type: none"> <li>- Select Speed</li> <li>-- 1)0.125x</li> <li>-- 2)0.25x</li> </ul> </li> <li>— <b>GPS</b></li> <li>— <b>PC Direct Mode</b></li> </ul>	<ul style="list-style-type: none"> <li>— <b>DEEP SKY TOUR</b> <ul style="list-style-type: none"> <li>- .....</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>— <b>Named Star</b> <ul style="list-style-type: none"> <li>- ...</li> </ul> </li> <li>— <b>Solar System</b> <ul style="list-style-type: none"> <li>- Mercury</li> <li>- Venus</li> <li>- Mars</li> <li>- Jupiter</li> <li>- Saturn</li> <li>- Uranus</li> <li>- Neptune</li> <li>- Pluto</li> <li>- Moon</li> </ul> </li> <li>— <b>NGC Catalog</b> <ul style="list-style-type: none"> <li>- NGC=</li> </ul> </li> <li>— <b>IC Catalog</b> <ul style="list-style-type: none"> <li>- IC=</li> </ul> </li> <li>— <b>Messier Catalog</b> <ul style="list-style-type: none"> <li>- Messier=</li> </ul> </li> <li>— <b>Caldwell Catalog</b> <ul style="list-style-type: none"> <li>- Cald # =</li> </ul> </li> <li>— <b>SAO Catalog</b> <ul style="list-style-type: none"> <li>- SAO 0000xx</li> </ul> </li> <li>— <b>Double Star</b> <ul style="list-style-type: none"> <li>- ...</li> </ul> </li> <li>— <b>Variable Star</b> <ul style="list-style-type: none"> <li>- ...</li> </ul> </li> <li>— <b>User Objects</b> <ul style="list-style-type: none"> <li>- Recall Object</li> <li>-- User obj. # ..</li> <li>- Edit Object</li> <li>-- 1) RA-DEC</li> <li>-- 2) AZALT</li> </ul> </li> </ul>	

Zum Einspielen einer neuen Firmware die **Tasten 8 + 0** beim Einschalten drücken!